


Sony AV Multi Out - распиновка

Автор: Administrator
23.02.2011 10:24 -



Available на Sony PlayStation видеоигр и некоторых других устройств.

Pin	Pin	Name	Название	D
1	GND	GND	Ground	3
2	RT	PT	Right Audio	П
3	GND	GND	Ground	3
4	LT	LT	Left Audio	Л
5	Y	Y	S-Video Y	
S-Video				
6	CVIDEO/SYNC	CVIDEO / SYNC	Composite Video/Sync	K
7	C	C	S-Video C	S
8	VGND	VGND	Video Ground	B
9	B	B	Blue	B
10	+5V	+5 B	+5 VDC	+
11	R	R	Red	K
12	G	G	Green	3